


Lecture 10: Reference Generation

[IFAC PB Ch 7, Ch 9 p. 68–72, these slides]

1. Transfer function approach
2. State-space approach
3. Nonlinear reference generation

1

Simplistic Reference Handling: Error Feedback




Problems:

- Step setpoint changes can introduce very large control signals
- The same controller $C(z)$ must be tuned to handle both disturbances and setpoint changes
 - No separation between the regulator problem and the servo problem


2

Quick Fixes

- Filter the reference signal



- Rate-limit the reference signal




- Avoid differentiating the reference signal
 - E.g. PID with derivative weighting $\gamma = 0$

3

A More General Solution

Use a two-degree-of-freedom (2-DOF) controller, e.g.:



Design procedure:

1. Design feedback controller H_{fb} to get good regulation properties (attenuation of load disturbances and measurement noise)
2. Design feedforward compensator H_{ff} to obtain the desired servo performance


4

PID Example

$$u = K(\beta y_{sp} - y + \frac{1}{T_I} \int (y_{sp} - y) d\tau + T_D \frac{d}{dt} (\gamma y_{sp} - y)) =$$

$$K(e + \frac{1}{T_I} \int e d\tau + T_D \frac{de}{dt}) +$$

$$\underbrace{K(\beta - 1)}_{K_1} y_{sp} + \underbrace{T_D K(\gamma - 1)}_{K_2} \frac{dy_{sp}}{dt}$$




Feedforward + Feedback

5


Equivalent Structures

A 2-DOF controller can be represented in many ways, e.g.:



6

Feedforward Design Using A Reference Model – Transfer Function Approach



- H_m – model that describes the desired servo performance
- H_{ff} – feedforward generator that makes y follow y_m

7

The transfer function from u_c to y is

$$H_{yu_c} = \frac{P(H_{ff} + CH_m)}{1 + PC}$$

Choose $H_{ff} = \frac{H_m}{P}$. Then

$$H_{yu_c} = \frac{P(\frac{H_m}{P} + CH_m)}{1 + PC} = H_m$$

Perfect model following!


8

Restrictions on the Model

In order for $H_{ff} = \frac{H_m}{P}$ to be causal and stable,

- H_m must have at least the same pole excess as P
- any unstable zeros of P must also be included in H_m

In practice, also poorly damped zeros of P (e.g. outside the heart-shaped region below) should be included in H_m



9

Example: PID Control of the Double Tank

Process:

$$G(s) = \frac{3}{(1 + 60s)^2}$$

Sampled process ($h = 3$):

$$H(z) = \frac{0.003627(z + 0.9672)}{(z - 0.9512)^2}$$


PID controller:

$$C(s) = K \left(1 + \frac{1}{sT_i} + \frac{sT_d}{1 + sT_d/N} \right)$$

with $K = 7$, $T_i = 45$, $T_d = 15$, $N = 10$, discretized using first-order hold.

10

Simulation with error feedback:



- Very large control signal at time 0
- Overshoot in the reference step response

11

Reference model:

$$G_m(s) = \frac{1}{(1 + 10s)^2}$$

Sampled reference model:


$$H_m(z) = \frac{0.036936(z + 0.8187)}{(z - 0.7408)^2}$$

Feedforward filter:

$$H_{ff}(z) = \frac{H_m(z)}{H(z)} = \frac{10.1828(z + 0.8187)(z - 0.9512)^2}{(z - 0.7408)^2(z + 0.9672)}$$

12

Simulation with reference model and feedforward:



- Perfect step response according to the model
- Unpleasant ringing in the control signal
 - due to cancellation of poorly damped process zero

13

Modified reference model that includes the process zero:


$$H_m(z) = \frac{0.034147(z + 0.9672)}{(z - 0.7408)^2}$$

New feedforward filter:

$$H_{ff}(z) = \frac{H_m(z)}{H(z)} = \frac{9.414(z - 0.9512)^2}{(z - 0.7408)^2}$$

14

Simulation with modified reference model:




- Ringing eliminated

15

Remark

In the implementation, both u_{ff} and y_m can be generated by a single dynamical system:



Matlab:

```
>> H = ... % define process
>> Hm = ... % define reference model
>> refgen = [Hm/H; Hm] % concatenate systems
>> minreal(ss(refgen)) % make minimal state-space realization
```

16

Simplistic Reference Handling in State Space

Replace $u(k) = -Lx(k)$ with

$$u(k) = L_c u_c(k) - Lx(k)$$

The pulse transfer function from $u_c(k)$ to $y(k)$ is


$$H(z) = C(zI - \Phi + \Gamma L)^{-1} \Gamma L_c = L_c \frac{B(z)}{A_m(z)}$$

In order to have unit static gain ($H(1) = 1$), L_c should be chosen as

$$L_c = \frac{1}{C(I - \Phi + \Gamma L)^{-1} \Gamma}$$

17

Feedforward Design Using a Reference Model – State Space Approach



The model should generate a reference trajectory x_m for the process state x (one reference signal per state variable)

The feedforward signal u_{ff} should make x follow x_m

18

Reference model:

$$\begin{aligned}x_m(k+1) &= \Phi_m x_m(k) + \Gamma_m u_c(k) \\ y_m(k) &= C_m x_m(k)\end{aligned}$$

Control law:

$$u(k) = L(x_m(k) - \hat{x}(k)) + u_{ff}(k)$$

- How to generate model states x_m that are compatible with the real states x ?
- How to generate the feedforward control u_{ff} ?

19

Design of the Reference Model

Start by choosing the model identical to the process, i.e.,

$$\begin{aligned}x_m(k+1) &= \Phi x_m(k) + \Gamma u_{ff}(k) \\ y_m(k) &= C x_m(k)\end{aligned}$$


Then modify the dynamics of the model as desired using state feedback ("within the model")

$$u_{ff}(k) = L_{cm} u_c(k) - L_m x_m(k)$$

Gives the model dynamics

$$\begin{aligned}x_m(k+1) &= (\Phi - \Gamma L_m) x_m(k) + \Gamma L_{cm} u_c(k) \\ y_m(k) &= C x_m(k)\end{aligned}$$

20



21

Design of the Reference Model

Design choices:

- L_m is chosen to give the model the desired eigenvalues
- L_{cm} is chosen to give the model the desired static gain

(The above model will have the same zeros as the plant. Additional zeros and poles can be added by extending the model, see IFAC PB.)

22


Complete State-Space Controller

The complete controller is given by

$$\begin{aligned}\hat{x}(k+1) &= \Phi \hat{x}(k) + \Gamma u(k) + K(y(k) - C \hat{x}(k)) && \text{(Observer)} \\ x_m(k+1) &= \Phi x_m(k) + \Gamma u_{ff}(k) && \text{(Reference model)} \\ u(k) &= L(x_m(k) - \hat{x}(k)) + u_{ff}(k) && \text{(Control signal)} \\ u_{ff}(k) &= -L_m x_m(k) + L_{cm} u_c(k) && \text{(Feedforward)}\end{aligned}$$

23

Design Example: Depth Control of Torpedoes



State vector:

$$x = \begin{pmatrix} q \\ \theta \\ y \end{pmatrix} = \begin{pmatrix} \text{pitch angular velocity} \\ \text{pitch angle} \\ \text{depth} \end{pmatrix}$$

Input signal:

$$u = \delta = \text{rudder angle}$$

24

Torpedo: Continuous-Time Model

Simple model:

$$\begin{aligned}\frac{dq}{dt} &= aq + b\delta \\ \frac{d\theta}{dt} &= q \\ \frac{dy}{dt} &= -V\theta + c\delta\end{aligned}$$

where $a = -2$, $b = -1.3$, and $V = 5$ (speed of torpedo)

$$\begin{aligned}\dot{x} &= \begin{pmatrix} a & 0 & 0 \\ 1 & 0 & 0 \\ 0 & -V & 0 \end{pmatrix} x + \begin{pmatrix} b \\ 0 \\ 0 \end{pmatrix} u \\ y &= \begin{pmatrix} 0 & 0 & 1 \end{pmatrix} x\end{aligned}$$

25

Torpedo: Sampled Model

Sample with $h = 0.2$

$$x(kh + h) = \begin{pmatrix} 0.67 & 0 & 0 \\ 0.165 & 1 & 0 \\ -0.088 & -1 & 1 \end{pmatrix} x(kh) + \begin{pmatrix} 0.214 \\ -0.023 \\ 0.008 \end{pmatrix} u(kh)$$

26

Torpedo: State Feedback

- $u(k) = -Lx(k)$
- load disturbance rejection

Desired continuous-time dynamic behaviour:

- two complex-conjugated poles with relative damping 0.5 and natural frequency ω_c
- one pole in $-\omega_c$
- a single parameter decides the dynamics

Desired characteristic polynomial

$$(s^2 + 2 \cdot 0.5 \cdot \omega_c s + \omega_c^2)(s + \omega_c) = s^3 + 2\omega_c s^2 + 2\omega_c^2 s + \omega_c^3$$

27

Corresponds in discrete time to

$$(z^2 + a_1 z + a_2)(z - e^{-\omega_c h})$$

where $a_1 = -2e^{-\zeta\omega_c h} \cos(\sqrt{1 - \zeta^2}\omega_c h)$, $a_2 = e^{-2\zeta\omega_c h}$ with $\zeta = 0.5$

28

Torpedo: State Feedback in Matlab

Matlab code

```
>> h = 0.2;
>> wc = 1; % speed of state feedback
>> pc = wc*roots([1 2 2 1]); % control poles in cont time
>> pcd = exp(pc*h); % control poles in disc time

>> L = place(Phi, Gam, pcd)
L =
-0.1452 -1.6047 0.1528
```

29

Torpedo: Observer Design

- $\hat{x}(k+1) = \Phi\hat{x}(k) + \Gamma u(k) + K(y(k) - C\hat{x}(k))$
- measurement noise rejection + state estimation

Observer Dynamics:

- the same pole layout as in the control design
- parametrized by ω_o instead of ω_c
- typically faster dynamics than the controller, e.g., $\omega_o = 2\omega_c$

Desired continuous-time characteristic polynomial:

$$(s + \omega_o)(s^2 + \omega_o s + \omega_o^2) = s^3 + 2\omega_o s^2 + 2\omega_o^2 s + \omega_o^3$$

Discrete time characteristic polynomial given from previous slide

30


Torpedo: Observer Design in Matlab

```
>> wo = 2; % speed of observer
>> po = wo*roots([1 2 2 1]); % observer poles in cont time
>> pod = exp(po*h); % observer poles in disc time

>> K = place(Phi',C',pod)
K =
    0
 -0.130
  0.460
```

Torpedo: Simplistic Approach

Simulation assuming naive approach ($u(k) = -L\hat{x}(k) + L_c u_c(k)$)



- Slow reference step response with overshoot

Torpedo: Model and Feedforward Design

$$x_m(k+1) = \Phi x_m(k) + \Gamma u_{ff}(k)$$

$$y_m(k) = C x_m(k)$$

Feedforward:

$$u_{ff} = -L_m x_m + l_r r$$

Desired characteristic polynomial:

$$(s + \omega_m)^3 = s^3 + 3\omega_m s^2 + 3\omega_m^2 s + \omega_m^3$$

(critically damped – important!)


- Parametrized using ω_m
- Chosen as $\omega_m = 2\omega_c$

Torpedo: Model and Feedforward Design in Matlab

Corresponding discrete time characteristic polynomial from Matlab


```
>> h = 0.2;
>> wm = 2; % speed of model
>> pm = wm*roots([1 3 3 1]); % model poles in cont time
>> pmd = exp(pm*h); % model poles in disc time
>> Lm = place(Phi,Gam,pmd)
Lm =
  1.518 -5.539 1.001
>> Hm = ss(Phi-Gam*Lm,Gam,C,0,h);
>> lcm = 1/dcgain(Hm)
lcm =
  1.001
```

Torpedo: Simulation Complete Controller




- Faster reference step response, no overshoot

Model states and feedforward signal:



- The model states and the feedforward signal are not affected by the load disturbance
- Open loop


Simulation without the feedforward signal ($u(k) = L(x_m(k) - \hat{x}(k))$):



- Does not work very well – the feedforward term is needed to get the desired reference step response

37

Simulation without the feedback term ($u(k) = u_{ff}(k)$):




- Does not work – the feedback is needed to handle the load disturbance

38

Nonlinear Reference Generation

Recall the state-space approach to reference generation:



Often, u_{ff} and x_m do not come from linear filters but are the result of solving an optimization problem, e.g.:

- Move a satellite to a given altitude with minimum fuel
- Position a mechanical servo in as short time as possible under a torque constraint
- Move the ball on the beam as fast as possible without losing it

39

General Solution

- Derive the feedforward (open-loop) control signal u_{ff} that solves the optimization problem
 - Course in Nonlinear Control (FRTN05, Lp Vt 2)
- The model state trajectories are generated by solving

$$\frac{dx_m}{dt} = Ax_m + Bu_{ff}$$

40

Example: Time-Optimal Control of Ball and Beam



State vector:

$$\begin{pmatrix} x \\ v \\ \phi \end{pmatrix} = \begin{pmatrix} \text{ball position} \\ \text{ball velocity} \\ \text{beam angle} \end{pmatrix}$$

Continuous-time state-space model:

$$\begin{aligned} \frac{dx}{dt} &= v \\ \frac{dv}{dt} &= -k_v \phi \quad (k_v \approx 10) \\ \frac{d\phi}{dt} &= k_\phi u \quad (k_\phi \approx 4.5) \end{aligned}$$

41

Optimization problem: Assume steady state. Move the ball from start position $x(0) = x_0$ to final position $x(t_f) = x_f$ in minimum time while respecting $-u_{\max} \leq u(t) \leq u_{\max}$.

Optimal control theory gives the optimal open-loop control law

$$u_{ff}(t) = \begin{cases} -u_0, & 0 \leq t < T \\ u_0, & T \leq t < 3T \\ -u_0, & 3T \leq t < 4T \end{cases}$$


where

$$\begin{aligned} u_0 &= \text{sgn}(x_f - x_0) u_{\max} \\ T &= \sqrt[3]{\frac{|x_f - x_0|}{2k_\phi k_v u_{\max}}} \\ t_f &= 4T \end{aligned}$$

42

Example: $u_{\max} = 1$, $x_0 = 0$, and $x_f = 5 \Rightarrow t_f = 1.538$

Optimal control signal:



("bang-bang" control)


43

Solving

$$\frac{d\phi_m}{dt} = k_\phi u_{ff}$$

gives

$$\phi_m(t) = \begin{cases} -k_\phi u_0 t, & 0 \leq t < T \\ k_\phi u_0 (t-2T), & T \leq t < 3T \\ -k_\phi u_0 (t-4T), & 3T \leq t \leq 4T \end{cases}$$




44

Solving

$$\frac{dv_m}{dt} = -k_v \phi_m$$

gives

$$v_m(t) = \begin{cases} k_\phi k_v u_0 t^2/2, & 0 \leq t < T \\ -k_\phi k_v u_0 (t^2/2 - 2Tt + T^2), & T \leq t < 3T \\ k_\phi k_v u_0 (t^2/2 - 4Tt + 8T^2), & 3T \leq t \leq 4T \end{cases}$$




45

Solving

$$\frac{dx_m}{dt} = v_m$$

gives

$$x_m(t) = \begin{cases} x_0 + k_\phi k_v u_0 t^3/6, & 0 \leq t < T \\ x_0 - k_\phi k_v u_0 (t^3/6 - Tt^2 + T^2t - T^3/3), & T \leq t < 3T \\ x_0 + k_\phi k_v u_0 (t^3/6 - 2Tt^2 + 8T^2t - 26T^3/3), & 3T \leq t \leq 4T \end{cases}$$



46

Control Design: Summary

- Regulator problem – reduce impact of load disturbances and measurement noise
 - Transfer function approach: design of feedback controller $H_{fb}(z)$, e.g. PID controller
 - State space approach: design of state feedback and observer
- Servo problem - make the output follow the setpoint in the desired way
 - Transfer function approach: design of model reference $H_m(z)$ and feedforward filter $H_{ff}(z)$
 - State space approach: design of combined reference and feedforward generator
 - * Linear or nonlinear reference generation

47