Welcome to

FRTN10 Multivariable Control

Anton Cervin

Department of Automatic Control
Lund University

Department of Automatic Control

- Founded 1965 by Karl Johan Åström (IEEE Medal of Honor)
- Approx. 50 employees
- Education for B, BME, C, D, E, F, I, K, M, N, Pi, W
- Research in complex systems, robotics, real-time systems, process control, automotive systems, biomedicine, . . .

Lecture 1 – Outline

1. Course program
2. Course introduction
3. Signals and systems
   - Review of system representations
   - Signal norm and system gain

Lecture 1 – Outline

1. Course program
2. Course introduction
3. Signals and systems
   - Review of system representations
   - Signal norm and system gain

Administration

Anton Cervin
Course responsible and lecturer

anton@control.lth.se
046-222 44 75
M:5145

Mika Nishimura
Course administrator

mika@control.lth.se
046-222 87 85
M:5141

Prerequisites

FRT010 Automatic Control, Basie Course or FRTN25 Automatic Process Control is required prior knowledge.

It is assumed that you have taken the basic courses in mathematics, including linear algebra and calculus in several variables, and preferably also systems & transforms or linear systems.

Course material

All course material is available in English. Most lectures are covered by the following textbook sold by KFS AB:

- Glad & Ljung: *Reglerteori – Flervariabla och olinjära metoder*, (2 uppl.), Studentlitteratur, 2003.
- English edition: Glad & Ljung: *Control Theory – Multivariable and Nonlinear Methods*, Taylor & Francis Ltd / CRC Press



All other material on the homepage:

- Lecture slides (also handed out)
- Lecture notes (for Lectures 1–8, 13)
- Exercise problems with solutions
- Laboratory assignments

`http://www.control.lth.se/course/FRTN10`

Lectures

The lectures (30 hours in total) are given by Anton Cervin on Mondays (w. 35–39, 41), Tuesdays (w. 35–36), and Thursdays (w. 35–41).

See the LTH schedule generator for details.

Exercise sessions and TAs

The exercise sessions (28 hours in total) are arranged in three groups:

Group	*Times*	*Room*	*Teaching Assistant*
1	Wed 10–12, Fri 8–10	Lab A	Marcus T. Andrén
2	Wed 13–15, Fri 10–12	Lab A	Josefin Berner
3	Wed 15–17, Fri 13–15	Lab A	Olof Troeng

Marcus T. Andrén

marcus@control.lth.se

Josefin Berner

josefinb@control.lth.se

Olof Troeng

oloft@control.lth.se

Laboratory experiments

The three laboratory sessions (12 hours in total) are mandatory. Booking lists are posted on the course homepage. You must sign up before the first session starts. Before each session there are pre-lab assignments that must be completed. No reports are required afterwards.

Lab	*Weeks*	*Booking*	*Room*	*Responsible*	*Process*
1	37–38	Aug 30	Lab C	Olof Troeng	Flexible linear servo
2	39–40	Sep 13	Lab C	Josefin Berner	Quadruple tank
3	41–42	Sep 27	Lab B	Marcus T. Andrén	Rotating crane



Exam

The exam is given on October 25 at 08:00–13:00.

A second occasion is on January 3, 2017.

The textbook, lecture notes, and lecture slides (with markings/notes) are allowed on the exam. You may also bring an *Automatic Control—Collection of Formulae*, standard mathematical tables (TEFYMA), and a pocket calculator.

Use of computers in the course

- In our lab rooms, use your personal student account or a common course account
- Matlab is used in both exercise sessions and laboratory sessions
  - Control System Toolbox
  - Simulink
  - CVX (`http://cvxr.com/cvx`, used in exercise session 12)
  - (Symbolic Math Toolbox)

Feedback and Q&A

For each course LTH uses the following feedback mechanisms

- CEQ (reporting / longer time scale)
- Student representatives (fast feedback)
  - Election of student representative ("kursombud")

We will be using Piazza for Q&A:

`https://piazza.com/lu.se/fall2016/frtn10/home`

Please post your questions here!

Course registration

Course registration in Ladok will be performed on Wednesday.

Put a mark next to your name on the registration list (or fill in your details on an empty row at the end).

If you decide to drop out during the first three weeks of the course, you should notify us so that we can unregister you in Ladok.

Do not forget to do “terminsregistrering”!

Lecture 1 – Outline

1. Course program
2. Course introduction
3. Signals and systems
   - Review of system representations
   - Signal norm and system gain

Multivariable control – Example 1

Multivariable control – Example 1



Example 2: Rollover control

Example 2: Rollover control



Example 3: DVD reader



- 3.5 m/s speed along track
- 0.022 μm tracking tolerance
- 100 μm deviations at ~23 Hz due to asymmetric discs

Focus and tracking control



Focus and tracking control



Example 4: Control of friction stir welding

Prototype FSW machine at the Swedish Nuclear Fuel and Waste Management Company (SKB) in Oskarshamn



Control of friction stir welding

Measurement variables:



- Temperatures (3 sensors)
- Motor torque
- Shoulder depth

Control variables:



- Tool rotation speed
- Weld speed
- Axial force

Control objectives:

- Keep weld temperature at 845 °C
- Keep shoulder depth at 1 mm

Contents of the course

Despite its name, this course is **not only about multivariable control**. You will also learn about:

- sensitivity and robustness
- design trade-offs and fundamental limitations
- stochastic control
- optimization of controllers

Outline of lectures

L1–L5 Specifications, models and loop-shaping by hand

L6–L8 Limitations on achievable performance

L9–L11 Controller optimization: analytic approach

L12–L14 Controller optimization: numerical approach

L15 Course review

Lecture 1: Systems and signals

Lecture 2: Stability and robustness



Lecture 3: Disturbance models





Lecture 4: Control synthesis in frequency domain



Lecture 5: Case study



Lecture 6: Multivariable zeros, singular values, gramians



$$G(s) = \begin{pmatrix} \frac{1}{s+2} & 1 \\ \frac{2}{s+2} & 1 \end{pmatrix}$$

Lecture 7: Fundamental limitations



Lecture 8: Decentralized control



Lecture 9: Linear-quadratic optimal control



$$\min_L \int_0^\infty \left(x^T Q_1 x + u^T Q_2 u \right) dt$$


u
P
v1
v2
y
Kalman
x̂
−
u
P
v1
v2
y
Kalman
x̂
L

Lecture 11: More on LQG



$$\min_{L,K} \mathrm{E}_{v_1,v_2} \left\{ x^T Q_1 x + u^T Q_2 u \right\}$$

Lecture 12: Youla parametrization, internal model control



ALL stabilizing controllers:

$$C(s) = \left[I - Q(s)P_{yu}(s)\right]^{-1} Q(s)$$

Minimize

$$\int_{-\infty}^{\infty} \Big| P_{zw}(i\omega) + P_{zu}(i\omega) \overbrace{\sum_k Q_k \phi_k(i\omega)}^{Q(i\omega)} P_{yw}(i\omega) \Big|^2 d\omega \quad \}$$

subject to constraints





Lecture 14: Controller simplification

$$C(s) = \frac{(s/1.3+1)(s/45+1)}{(s/1.2+1)(s^2+0.4s+1.04)(s/50+1)} \approx \frac{s^2-2.3s+57}{s^2+0.41s+1.1}$$



Lecture 1 – Outline

1. Course program
2. Course introduction
3. Signals and systems
   - Review of system representations
   - Signal norm and system gain

Systems

A **system** is a mapping from the input signal $u(t)$ to the output signal $y(t)$, $-\infty < t < \infty$:

$$y = \mathcal{S}(u)$$

System properties

A system $\mathcal{S}$ is

- **causal** if $y(t_1)$ only depends on $u(t)$, $-\infty < t \leq t_1$,
  non-causal otherwise

- **static** if $y(t_1)$ only depends on $u(t_1)$,
  dynamic otherwise

- **discrete-time** if $u(t)$ and $y(t)$ are only defined for a countable set of discrete time instances $t = t_k,\ k = 0, \pm 1, \pm 2, \ldots$,
  continuous-time otherwise

System properties (cont'd)

A system $\mathcal{S}$ is

- **single-variable** or **scalar** if $u(t)$ and $y(t)$ are scalar signals, **multivariable** otherwise
- **time-invariant** if $y(t) = \mathcal{S}(u(t))$ implies $y(t+\tau) = \mathcal{S}(u(t+\tau))$, **time-varying** otherwise
- **linear** if $\mathcal{S}(\alpha_1 u_1 + \alpha_2 u_2) = \alpha_1 \mathcal{S}(u_1) + \alpha_2 \mathcal{S}(u_2)$, **nonlinear** otherwise

LTI system representations

We will mainly deal with continuous-time **linear time-invariant** (LTI) systems in this course

For LTI systems, the same input–output mapping $\mathcal{S}$ can be represented in a number of equivalent ways:

- linear ordinary differential equation
- linear state-space model
- transfer function
- impulse response
- step response
- frequency response
- ...

State-space models



Linear state-space model:

$$\begin{cases} \dot{x} = Ax + Bu \\ y = Cx + Du \end{cases}$$

Solution:

$$y(t) = Ce^{At}x(0) + \int_0^t Ce^{A(t-\tau)}Bu(\tau)d\tau + Du(t)$$

Mini-problem 1

$$\dot{x}_1 = -x_1 + 2x_2 + u_1 + u_2 - u_3$$
$$\dot{x}_2 = -5x_2 + 3u_2 + u_3$$
$$y_1 = x_1 + x_2 + u_3$$
$$y_2 = 4x_2 + 7u_1$$

How many state variables, inputs and outputs?

Determine the matrices A, B, C, D to write the system as

$$\begin{cases} \dot{x} = Ax + Bu \\ y = Cx + Du \end{cases}$$

Change of coordinates

$$\begin{cases} \dot{x} = Ax + Bu \\ y = Cx + Du \end{cases}$$

Change of coordinates

$$z = Tx, \quad T \text{ invertible}$$

$$\begin{cases} \dot{z} = T\dot{x} = T(Ax + Bu) & = T(AT^{-1}z + Bu) = TAT^{-1}z + TBu \\ y = Cx + Du & = CT^{-1}z + Du \end{cases}$$

Note: There are infinitely many different state-space representations of the same system $\mathcal{S}$

Impulse response



Common experiment in medicine and biology

$$g(t) = \int_0^t Ce^{A(t-\tau)}B\delta(\tau)d\tau + D\delta(t) = Ce^{At}B + D\delta(t)$$

$$y(t) = \int_0^t g(t-\tau)u(\tau)d\tau = (g * u)(t)$$

Step response



Common experiment in process industry

$$y(t) = \int_0^t g(t-\tau)u(\tau)d\tau = \int_0^t g(\tau)d\tau$$

Transfer function



$$G(s) = \mathcal{L}\{g(t)\}$$

$$y(t) = (g * u)(t) \quad \Leftrightarrow \quad Y(s) = G(s)U(s)$$

Conversion from state-space form to transfer function:

$$G(s) = C(sI - A)^{-1}B + D$$

Transfer function

A transfer function is **rational** if it can be written as

$$G(s) = \frac{B(s)}{A(s)}$$

where $B(s)$ and $A(s)$ are polynomials in s

It is **proper** if $\deg B \leq \deg A$ and **strictly proper** if $\deg B < \deg A$

A rational and proper transfer function can be converted to state-space form (see Collection of Formulae)

Frequency response



Assume stable transfer function $G = \mathcal{L}g$. Input $u(t) = \sin \omega t$ gives

$$y(t) = \int_0^t g(\tau)u(t-\tau)d\tau = \text{Im}\left[\int_0^t g(\tau)e^{-i\omega\tau}d\tau \cdot e^{i\omega t}\right]$$

$$[t \to \infty] = \text{Im}\left(G(i\omega)e^{i\omega t}\right) = |G(i\omega)|\sin\left(\omega t + \arg G(i\omega)\right)$$

After a transient, also the output becomes sinusoidal

The Nyquist diagram



The Bode diagram



$$G = G_1 G_2 G_3 \qquad \begin{cases} \log|G| = \log|G_1| + \log|G_2| + \log|G_3| \\ \arg G = \arg G_1 + \arg G_2 + \arg G_3 \end{cases}$$

Each new factors enter additively!

The Bode diagram



$$G = G_1 G_2 G_3 \qquad \begin{cases} \log|G| = \log|G_1| + \log|G_2| + \log|G_3| \\ \arg G = \arg G_1 + \arg G_2 + \arg G_3 \end{cases}$$

Each new factors enter additively!

Hint: Set Matlab scales

» `ctrlpref`

Signal norm and system gain

How to quantify

- the "size" of the signals u and y
- the "maximum amplification" between u and y

Signal norm and system gain

The L_2 norm of a signal $y(t) \in \mathbf{R}^n$ is defined as

$$\|y\|_2 := \sqrt{\int_0^\infty |y(t)|^2 dt} = \sqrt{\frac{1}{2\pi}\int_{-\infty}^{\infty} |Y(i\omega)|^2 d\omega}$$

The last equality is known as Parseval's theorem

The L_2 gain of a system $\mathcal{S}$ with input u and output $\mathcal{S}(u)$ is defined as

$$\|\mathcal{S}\| := \sup_u \frac{\|\mathcal{S}(u)\|_2}{\|u\|_2}$$

Mini-problem 2

What are the gains of the following scalar LTI systems?

1. $y(t) = -u(t)$ (a sign shift)
2. $y(t) = u(t - T)$ (a time delay)
3. $y(t) = \int_0^t u(\tau) d\tau$ (an integrator)
4. $y(t) = \int_0^t e^{-(t-\tau)} u(\tau) d\tau$ (a first order filter)

L_2-gain for LTI systems

Consider a stable LTI system $\mathcal{S}$ with input u and output $\mathcal{S}(u)$ having the transfer function $G(s)$. Then

$$\|\mathcal{S}\| := \sup_u \frac{\|\mathcal{S}(u)\|_2}{\|u\|_2} = \sup_\omega |G(i\omega)| := \|G\|_\infty$$

Proof. Let $y = \mathcal{S}(u)$. Then

$$\|y\|^2 = \frac{1}{2\pi}\int_{-\infty}^{\infty} |Y(i\omega)|^2 d\omega = \frac{1}{2\pi}\int_{-\infty}^{\infty} |G(i\omega)|^2 \cdot |U(i\omega)|^2 d\omega \leq \|G\|_\infty^2 \|u\|^2$$

The inequality is arbitrarily tight when $u(t)$ is a sinusoid near the maximizing frequency.

(How to interpret $|G(i\omega)|$ for matrix transfer functions will be explained in Lecture 2.)